



**NOTES:**  
This is a low tolerance product. It is extremely important that the walls are constructed at the thickness called out per the plans. Any extra drywall compound buildup at the header or upper corners of the rough opening will need to be corrected before the aluminum frames can be installed. All rock needs to be cut tight to the studs and the opening/wall needs to be square and plumb.

Check your local jurisdiction for fire code concerning the type of wood to use for backing. All backing done by others.

**FRONT VIEW - BLOCKING**  
SCALE 3/4"=1'-0"